

# PRODUCT

---

## INFORMATION



PRATT & LAMBERT PAINTS

### Ovation™ Classic Suede Interior Textured Finish

PZ7400 / F7400

#### DESCRIPTION :

This fabric-like textured finish creates a suede effect that is perfect for casual living rooms, dining rooms and bedrooms. It is a two-coat system, which creates a subtle texture and color depth.

#### USES :

Recommended for properly prepared wallboard, plaster, wood, metal or masonry surfaces.

**SIZES:** Gallons, Quarts

**COLORS:** May be tinted into 30 color choices.

#### RECOMMENDED SYSTEMS :

##### NEW WORK :

##### NEW WOOD

1 coat of SUPRIME Interior Alkyd Wall & Trim Primer or  
1 coat SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer  
2 coats of Ovation Classic Suede applied per label instructions

##### METAL

1 coat of Tech-gard Alkyd Metal Primer (Best) or Tech-gard Acrylic Prime or Finish  
2 coats of Ovation Classic Suede applied per label instructions

##### PLASTER

New - After dry, 1 coat of SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer  
Old >60 days, 1 coat of SUPRIME Interior Alkyd Wall & Trim Primer  
2 coats of Ovation Classic Suede applied per label instructions

##### MASONRY OR AGGREGATE BLOCK

2 coats of Ovation Classic Suede applied per label instructions  
(For a filled effect, use PRO-HIDE Silver Heavy Duty Latex Block Filler as a first coat)

##### DRYWALL

1 coat of SUPRIME Latex Wall Primer  
2 coats of Ovation Classic Suede applied per label instructions

##### REPAINT :

Spot prime bare areas with appropriate primer  
2 coats of Ovation Classic Suede applied per label instructions

#### PRODUCT DETAIL :

<b>Vehicle:</b>	Latex
<b>Sheen:</b>	N/A
<b>% Solids:</b>	By Weight: 53% By Volume: 39%
<b>Wt./Gallon:</b>	10.9 lbs.
<b>Flashpoint:</b>	499°F
<b>VOC Level:</b>	106 g/l
<b>Thinner:</b>	Water
<b>Cleanup:</b>	Soap and water
<b>Dry Time:</b>	@ 77°F (25°C) 50% RH: To Touch: 0.5 Hour To Recoat: 4.0 Hours
<b>Coverage:</b>	150 sq. ft./gallon

#### APPLICATION :

<b>Brush:</b>	3" Nylon/Polyester Brush
<b>Roller:</b>	4" P&L Specialty Edge Roller 9" P&L Specialty Roller

#### Care Of Freshly

**Painted Surface:** Ovation Classic Suede may be gently washed after 30 days.

Technical Information Line:  
1-800-BUY-PRAT (1-800-289-7728)  
[www.prattandlambert.com](http://www.prattandlambert.com)

## SURFACE PREPARATION:

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

### General

Remove all surface contamination by washing with appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with Pratt & Lambert SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer.

### Drywall

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

### Masonry, Concrete, Cement, Block, Stucco, Brick

Allow new surfaces to cure according to supplier's recommendations, or at least 7 days.

Remove all surface contamination (dirt, dust, grease, oil, peeling paint, heavy chalk, efflorescence, laitance, concrete dust, etc.) by washing with an appropriate cleaner; if necessary, pressure wash with a minimum of 2100 psi, rinse thoroughly and allow to dry. Remove all form release and curing agents. On tilt-up and poured-in-place concrete, commercial detergents or sandblasting may be necessary to remove sealers, release compounds, and to provide an anchor pattern.

Repair or replace damaged or defective substrates as needed.

Allow brick to age for 1 year prior to coating.

On interior surfaces with a pH from 9 to 13, use Pro-Hide Gold Acrylic Concrete and Stucco Primer.

### Plaster

Bare plaster must be cured and hard. Treat textured, soft, porous, or powdery plaster with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.

### Wood

Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.

### Aluminum and Galvanized Steel

Wash with appropriate cleaner to remove any oil, grease, or other surface contamination. Remove all corrosion with sandpaper, steel wool, or other abrading method.

### Steel

Remove rust and mill scale using sandpaper, steel wool, or other abrading method. Prime bare steel the same day as cleaned.

### Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

## CLEANUP INFORMATION:

Clean spills and splatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using all solvents.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Pratt & Lambert Paints. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Pratt & Lambert dealer or representative to obtain the most recent Product Data Sheet.



## PRATT & LAMBERT PAINTS

## APPLICATION:

Apply at temperatures above 50°F.

No reduction necessary.

Use application tools recommended on front page.

**Do NOT apply by conventional or airless spray.**

Step 1: Over a non-slick base coat, apply Classic Suede to the surface. Make sure walls are clean, dry and dull before beginning.

Step 2: Starting at the top corner of the wall, cut in 18" long strips at the ceiling edge and corner with a brush. Texture the wet finish by rolling over it with the P&L Ovation 4" Specialty Edge Roller. You must apply this product more thickly than you would regular paint to achieve the best results.

Step 3: Use the P&L Ovation 9" Specialty Roller to roll on Classic Suede in 18" x 18" sections. Continue to cut in at the corner and roll 18" sections down the wall. For proper results, reload the roller for each section until you have completed the whole column.

Step 4: Once you have completed a column, you must go over it with a light ceiling-to-floor sweep without reloading the roller. Repeat this process until you have covered the entire area. Allow to dry thoroughly (at least 4 hours). This coat will look somewhat uneven.

Step 5: Apply the second coat with the 3" brush in a random criss-cross pattern of large, sweeping X's. Blend the brush strokes so the final effect is soft and mottled.

## CAUTIONS:

For interior use only.

Protect from freezing.

Do not shake excessively.

Not for use on horizontal surfaces (floors, roofs, decks, etc.) or where water will collect.