

# PRODUCT

---

## INFORMATION



PRATT & LAMBERT PAINTS

### Accolade®

## Interior Acrylic Latex Semi-Gloss

PZ4100 / PF4100 Series  
RZ4100 / RF4100 Series

#### DESCRIPTION:

A premium quality, spatterless, 100% acrylic semi-gloss enamel formulated for exceptional flow and leveling, superior adhesion and excellent mar resistance.

#### USES:

Recommended for wood, metal, drywall, plaster, masonry and previously painted surfaces such as walls, ceilings, trim, cabinets, doors and window frames.

**SIZES:** Fives, Gallons, Quarts

#### COLORS:

All Base 1, Base 2 and Base 3 Colors, Super One-Coat White, Designer White

#### RECOMMENDED SYSTEMS:

##### NEW WORK:

##### NEW WOOD

1 coat of SUPRIME Interior Alkyd Wall & Trim Primer or  
1 coat SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer  
1 or 2 coats of Accolade Interior Acrylic Latex Semi-Gloss

##### METAL

1 coat of Tech-gard Alkyd Metal Primer (Best) or Tech-gard Acrylic Prime or Finish  
1 or 2 coats of Accolade Interior Acrylic Latex Semi-Gloss

##### PLASTER

New - After dry, 1 coat of SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer  
Old >60 days, 1 coat of SUPRIME Interior Alkyd Wall & Trim Primer  
1 or 2 coats of Accolade Interior Acrylic Latex Semi-Gloss

##### MASONRY OR AGGREGATE BLOCK

1 or 2 coats of Accolade Interior Acrylic Latex Semi-Gloss  
(For a filled effect, use PRO-HIDE Silver Heavy Duty Latex Block Filler as a first coat)

##### DRYWALL

1 coat of SUPRIME Interior Latex Wall Primer  
1 or 2 coats of Accolade Interior Acrylic Latex Semi-Gloss

##### REPAINT:

Spot prime bare areas with appropriate primer  
1 or 2 coats of Accolade Interior Acrylic Latex Semi-Gloss

#### PRODUCT DETAIL:

<b>Vehicle:</b>	100% Acrylic Latex
<b>Sheen:</b>	Semi-Gloss (30-40 @ 60°)
<b>% Solids:</b>	By Weight: 47% By Volume: 36%
<b>Wt./Gallon:</b>	10.1 lbs.
<b>Flashpoint:</b>	N/A
<b>VOC Level:</b>	Max 150 g/l (1.25 lbs./gal.)
<b>Thinner:</b>	Water
<b>Cleanup:</b>	Soap and water
<b>Dry Time:</b>	@ 77°F (25°C) 50% RH: To Touch: 0.5 Hour To Recoat: 4.0 Hours Use: 4.0 Hours

#### Rec. Film

**Thickness:** Dry: 1.4 Mils  
Wet: 4.0 Mils

**Coverage:** 400 sq. ft./gallon

#### APPLICATION:

<b>Brush:</b>	Nylon or Polyester
<b>Roller:</b>	3/8" nap cover
<b>Pad:</b>	Standard
<b>Conv. Spray:</b>	Thin with up to 1 pint water
<b>Airless Spray:</b>	At package consistency

**Limitations:** Due to high binder content, allow to dry overnight to determine final sheen.

Technical Information Line:  
1-800-BUY-PRAT (1-800-289-7728)  
[www.prattandlambert.com](http://www.prattandlambert.com)

## SURFACE PREPARATION:

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

### General

Remove all surface contamination by washing with appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with Pratt & Lambert SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer.

### Drywall

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

### Masonry, Concrete, Cement, Block, Stucco, Brick

Allow new surfaces to cure according to supplier's recommendations, or at least 7 days.

Remove all surface contamination (dirt, dust, grease, oil, peeling paint, heavy chalk, efflorescence, laitance, concrete dust, etc.) by washing with an appropriate cleaner; if necessary, pressure wash with a minimum of 2100 psi, rinse thoroughly and allow to dry.

Remove all form release and curing agents. On tilt-up and poured-in-place concrete, commercial detergents or sandblasting may be necessary to remove sealers, release compounds, and to provide an anchor pattern.

Repair or replace damaged or defective substrates as needed.

Allow brick to age for 1 year prior to coating.

On interior surfaces with a pH from 9 to 13, use Pro-Hide Gold Acrylic Concrete and Stucco Primer.

### Plaster

Bare plaster must be cured and hard. Treat textured, soft, porous, or powdery plaster with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.

### Wood

Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.

### Aluminum and Galvanized Steel

Wash with appropriate cleaner to remove any oil, grease, or other surface contamination. Remove all corrosion with sandpaper, steel wool, or other abrading method.

### Steel

Remove rust and mill scale using sandpaper, steel wool, or other abrading method. Prime bare steel the same day as cleaned.

### Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

## CLEANUP INFORMATION:

Clean spills and splatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using all solvents.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Pratt & Lambert Paints. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Pratt & Lambert dealer or representative to obtain the most recent Product Data Sheet.



## PRATT & LAMBERT PAINTS

### APPLICATION:

Apply at temperatures above 50°F.  
No reduction necessary.

#### Brush

Use a nylon/polyester brush.

#### Roller

Use a 3/8" nap synthetic roller cover.

#### Spray-Airless

Pressure ..... 2100 psi

Tip ..... .015 - .019

#### Spray-Conventional

*Thin with up to 1 pint of water*

Air Pressure ..... 40-60 psi

Fluid Pressure ..... 20 psi

Cap/Tip ..... 704/FX

### TIPS TO IMPROVE

#### PERFORMANCE:

- Clean the surface thoroughly.
- Prepare the substrate to create a uniform surface.
- Patch cracks, crevices, and through-wall openings using proper sealant or patch.
- Fill voids and openings around window and doors using proper sealant or patch.
- Caulk as needed using quality latex or siliconized latex caulk or sealant.

#### MAINTENANCE:

To assure maximum washability and durability, wait at least two weeks before washing the dry paint film. When removing stains, dirt, and marks, use a soft cloth or sponge with water or other general purpose household cleaner. Penetrating stains and marks can be removed either by applying a solution of household bleach in water and then rinsing with clean water; or, by carefully using an abrasive cleaner and water.

#### CAUTIONS:

For interior use only.  
Protect from freezing.  
Do not shake excessively.  
Not for use on horizontal surfaces (floors, roofs, decks, etc.) or where water will collect.