

PRODUCT

INFORMATION



PRATT & LAMBERT PAINTS

Accolade®

Exterior Acrylic Latex Eggshell

PZ4200 / PF4200 Series

RZ4200 / RF4200 Series

Low Temperature Application



DESCRIPTION:

A top quality, fast drying, spatterless, 100% acrylic eggshell house and trim finish, this high solids house paint resists blistering, chipping, peeling and chalking for years. This product may be and may be applied in temperatures as low as 35° F.

USES:

Recommended for exterior wood, metal, aluminum, vinyl and masonry surfaces such as siding, shingles, trim, doors, window frames, shutters and other decorative objects.

SIZES: Fives, Gallons, Quarts

COLORS: All Base 1, Base and Base 3 Colors, Super One-Coat White

RECOMMENDED SYSTEMS:

NEW WORK:

NEW WOOD

Spot prime knots with SUPRIME Int/Ext Odorless Stain Blocker

1 coat of SUPRIME Exterior Alkyd Wood Primer (Best) or

1 coat SUPRIME Exterior Latex Wood Primer

1 or 2 coats of Accolade Exterior Acrylic Latex Eggshell

FIBERBOARD, HARDBOARD, CEDAR OR REDWOOD

Spot prime knots with SUPRIME Int/Ext Odorless Stain Blocker

1 coat of SUPRIME Exterior Alkyd Wood Primer

(A second coat of primer may be necessary to block tannin stains on redwood and cedar)

1 or 2 coats of Accolade Exterior Acrylic Latex Eggshell

VINYL OR ALUMINUM SIDING

1 or 2 coats of Accolade Exterior Acrylic Latex Eggshell

(On vinyl siding, do not use colors darker than the original siding color)

METAL

1 coat of Tech-gard Alkyd Metal Primer (Best) or Tech-gard Acrylic Prime or Finish

1 or 2 coats of Accolade Exterior Acrylic Latex Eggshell

MASONRY OR AGGREGATE BLOCK

Allow new masonry to dry for 30 days

1 or 2 coats of Accolade Exterior Acrylic Latex Eggshell

(For a filled effect on masonry, use PRO-HIDE Silver Heavy Duty Latex Block Filler as a first coat)

REPAINT:

Spot prime bare areas with appropriate primer

1 or 2 coats of Accolade Exterior Acrylic Latex Eggshell

The information, ratings and opinions stated here pertain to the materials offered at the time of the publication. The data represents the results of tests believed to be reliable. Published technical data and instructions are subject to change.

1/05

PRODUCT DETAIL:

Vehicle:	100% Acrylic Latex
Sheen:	Eggshell (15-25 @ 85°)
% Solids:	By Weight: 52% By Volume: 40%
Wt./Gallon:	10.9 lbs.
Flashpoint:	N/A
VOC Level:	Max 150 g/l (1.23 lbs./gal.)
Thinner:	Water
Cleanup:	Soap and water
Dry Time:	@ 77°F (25°C) 50% RH: To Touch: 0.5 Hour To Recoat: 2.0 Hours Use: 2.0 Hours
Rec. Film Thickness:	Dry: 1.6 Mills Wet: 4.0 Mills
Coverage:	400 sq. ft./gallon

APPLICATION:

Brush:	Nylon or Polyester
Roller:	3/8" nap cover
Pad:	Standard
Conv. Spray:	Thin with up to 1 pint water
Airless Spray:	At package consistency

Limitations: DO NOT apply when air, surface or product temperature is below 35°F (10°C) or if temperatures might drop to this level within 4 hours after application.

Technical Information Line:
1-800-BUY-PRAT (1-800-289-7728)
www.prattandlambert.com

SURFACE PREPARATION:

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Exterior Drywall

Fill cracks and nail holes with an exterior grade patching paste/spackle and sand smooth. Remove all sanding dust.

Masonry, Concrete, Cement, Block, Stucco, Brick

Allow new surfaces to cure according to supplier's recommendations, or at least 7 days.

Remove all surface contamination (dirt, dust, grease, oil, peeling paint, heavy chalk, efflorescence, laitance, concrete dust, etc.) by washing with an appropriate cleaner; if necessary, pressure wash with a minimum of 2100 psi, rinse thoroughly and allow to dry.

Remove all form release and curing agents. On tilt-up and poured-in-place concrete, commercial detergents or sandblasting may be necessary to remove sealers, release compounds, and to provide an anchor pattern.

Repair or replace damaged or defective substrates as needed.

Allow brick to weather for 1 year prior to coating.

On surfaces with a pH from 9 to 13, use Pro-Hide Gold Acrylic Concrete and Stucco Primer.

Wood

Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.

Aluminum and Galvanized Steel

Wash with appropriate cleaner to remove any oil, grease, or other surface contamination.

Remove all corrosion with sandpaper, steel wool, or other abrading method.

Steel

Remove rust and mill scale using sandpaper, steel wool, or other abrading method. Prime bare steel the same day as cleaned.

Vinyl

Clean the surface thoroughly by scrubbing with warm, soapy water. Rinse thoroughly.

Caulking

Fill gaps between windows, doors, trim, and other through-wall openings with latex or siliconized latex caulk after priming the surface.

Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting.

Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

CLEANUP INFORMATION:

Clean spills and splatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using all solvents.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Pratt & Lambert Paints. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Pratt & Lambert dealer or representative to obtain the most recent Product Data Sheet.



PRATT & LAMBERT PAINTS

APPLICATION:

Apply at temperatures above 50°F.

On large expanses of metal siding, the **air, surface, and material temperatures** must be 50°F or higher.

Brush

Use a nylon/polyester brush.

Roller

Use a 3/8" nap synthetic roller cover.

Spray—Airless

Pressure 2100 psi

Tip017-.021

Spray—Conventional

Thin with up to 1 pint of water

Air Pressure 40-60 psi

Fluid Pressure 10-20 psi

Cap/Tip 704/FX

TIPS TO IMPROVE

PERFORMANCE:

- Clean the surface thoroughly.
- Prepare the substrate to create a uniform surface.
- Patch cracks, crevices, and through-wall openings using proper sealant or patch.
- Fill voids and openings around window and doors using proper sealant or patch.
- Caulk as needed using quality latex or siliconized latex caulk or sealant.

MAINTENANCE:

To assure maximum washability and durability, wait at least two weeks before washing the dry paint film. When removing stains, dirt, and marks, use a soft cloth or sponge with water or other general purpose household cleaner. Penetrating stains and marks can be removed either by applying a solution of household bleach in water and then rinsing with clean water; or, by carefully using an abrasive cleaner and water.

CAUTIONS:

For exterior use only.

Protect from freezing.

Do not shake excessively.

Not for use on horizontal surfaces

(floors, roofs, decks, etc.) or where water will collect.