

# PRODUCT

---

## INFORMATION



PRATT & LAMBERT PAINTS

### Ovation™ Opulence Interior Metallic Semi-Gloss

Z7600 / Z7610 / Z7620  
F7600 / F7610 / F7620

#### DESCRIPTION:

These gold, silver and pearl metallic colors create a shimmering effect on trim work and various accessories, such as moldings, frames and trim. This finish is perfect for achieving a formal or antiqued look.

**USES:** Recommended for trim work and accent pieces.

**SIZES:** Quarts, Gallons (Special Order Only)

**COLORS:** May be tinted into 20 color choices.

#### RECOMMENDED SYSTEMS:

##### NEW WORK:

##### NEW WOOD

Spot prime knots with SUPRIME Interior Alkyd Wall & Trim Primer  
1 coat of SUPRIME Interior Alkyd Wall & Trim Primer (Best) or SUPRIME Int/Ext  
100% Acrylic Multi-Purpose Primer  
2 coats base coat in a satin or semi-gloss finish  
1 or 2 coats Ovation Opulence, applied per label directions

##### METAL

1 coat of Tech-gard Alkyd Metal Primer (Best) or Tech-gard Acrylic Prime or Finish  
2 coats base coat in a satin or semi-gloss finish  
1 or 2 coats Ovation Opulence, applied per label directions

##### PLASTER

New - After dry, 1 coat of SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer  
Old (>60 days), 1 coat of SUPRIME Interior Alkyd Wall & Trim Primer  
2 coats base coat in a satin or semi-gloss finish  
1 or 2 coats Ovation Opulence, applied per label directions

##### DRYWALL

1 coat of SUPRIME Latex Wall Primer  
2 coats base coat in desired color and finish  
1 or 2 coats Ovation Opulence, applied per label directions

##### MASONRY OR AGGREGATE BLOCK

Allow new masonry to dry for 30 days  
2 coats base coat in satin or semi-gloss finish  
1 or 2 coats Ovation Opulence, applied per label directions

##### REPAINT:

Spot prime bare areas with appropriate primer  
2 coats base coat in a satin or semi-gloss finish  
1 or 2 coats Ovation Opulence, applied per label directions

The information, ratings and opinions stated here pertain to the materials offered at the time of the publication. The data represents the results of tests believed to be reliable. Published technical data and instructions are subject to change.  
1/04

#### PRODUCT DETAIL:

<b>Vehicle:</b>	Latex
<b>Sheen:</b>	Semi-Gloss (35-45 @ 60°)
<b>% Solids:</b>	By Weight: 42% By Volume: 35%
<b>Wt./Gallon:</b>	9.0 lbs.
<b>Flashpoint:</b>	499°F
<b>VOC Level:</b>	<220 g/l
<b>Thinner:</b>	Water
<b>Cleanup:</b>	Soap and water
<b>Dry Time:</b>	@ 77°F (25°C) 50% RH: To Touch: 0.5 Hour To Recoat: 4.0 Hours
<b>Coverage:</b>	80-100 sq. ft./quart 350-400 sq. ft./gallon

#### APPLICATION:

<b>Brush:</b>	Nylon/Polyester Brush
<b>Sponge:</b>	Natural sea sponge
<b>Roller:</b>	1/4" nap synthetic cover

#### Care Of Freshly

**Painted Surface:** Ovation Opulence may be gently washed after 30 days.

Technical Information Line:  
1-800-BUY-PRAT (1-800-289-7728)  
[www.prattandlambert.com](http://www.prattandlambert.com)



## PRATT & LAMBERT PAINTS

### SURFACE PREPARATION:

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

#### General

Remove all surface contamination by washing with appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with Pratt & Lambert SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer.

#### Drywall

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

#### Masonry, Concrete, Cement, Block, Stucco, Brick

Allow new surfaces to cure according to supplier's recommendations, or at least 7 days. Remove all surface contamination (dirt, dust, grease, oil, peeling paint, heavy chalk, efflorescence, laitance, concrete dust, etc.) by washing with an appropriate cleaner; if necessary, pressure wash with a minimum of 2100 psi, rinse thoroughly and allow to dry. Remove all form release and curing agents. On tilt-up and poured-in-place concrete, commercial detergents or sandblasting may be necessary to remove sealers, release compounds, and to provide an anchor pattern.

Repair or replace damaged or defective substrates as needed.

Allow brick to age for 1 year prior to coating.

On interior surfaces with a pH from 9 to 13, use Pro-Hide Gold Acrylic Concrete and Stucco Primer.

#### Plaster

Bare plaster must be cured and hard. Treat textured, soft, porous, or powdery plaster with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.

#### Wood

Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.

#### Aluminum and Galvanized Steel

Wash with appropriate cleaner to remove any oil, grease, or other surface contamination. Remove all corrosion with sandpaper, steel wool, or other abrading method.

#### Steel

Remove rust and mill scale using sandpaper, steel wool, or other abrading method. Prime bare steel the same day as cleaned.

#### Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

### CLEANUP INFORMATION:

Clean spills and splatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water.

### APPLICATION:

*For Best Results, Experiment On A Piece Of Scrap Material Before Proceeding With The Job.*

Do not apply at temperatures below 50°F or when air or surface temperatures may drop below 50°F within 48 hours.

No reduction necessary.

Many effects can be achieved using Ovation Opulence over your chosen base coat. Shimmer, Shantung Silk, Damask and Sponging are just examples of what can be done with this product. Ovation Opulence can be used as a full finish coat over a base coat to create a crisp, brilliant accent to any piece.

**Please refer to the Pratt & Lambert Ovation Technique book for ideas and effect creation instructions.**

#### Brush

Use a nylon/polyester brush.

#### Sponge

Use a natural sea sponge.

#### Roller

Use a 1/4" nap synthetic cover.

#### Spray-Airless

Pressure ..... 2000 psi

Tip ..... .017 - .021

#### Spray-Conventional

*Reduce up to 1 pint per gallon*

Air Pressure ..... 40-60 psi

Fluid Pressure ..... 15-20 psi

Cap/Tip ..... 704/FX

### CAUTIONS:

For interior use only.

Protect from freezing.

Do not shake excessively.

Not for use on horizontal surfaces (floors, roofs, decks, etc.) or where water will collect.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Pratt & Lambert Paints. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Pratt & Lambert dealer or representative to obtain the most recent Product Data Sheet.