

# PRODUCT

---

## INFORMATION



PRATT & LAMBERT PAINTS

### PRO-HIDE<sup>®</sup> Silver High Build Interior Latex Eggshell

Z8910 / F8910- White

Z8920 / F8920 - Antique White

Z8930 / F8930 - Swiss Coffee

#### DESCRIPTION:

This product is ideal for filling and surfacing imperfections in new or existing drywall construction. When spray applied, Pro-Hide Silver High Build Interior Latex Eggshell will provide a smooth and uniform finish over drywall paper and joints, while minimizing imperfections such as fuzz, sanding grooves (on a smaller scale), nicks and pinholes.

#### USES:

Recommended for drywall, cured plaster, and to create decorative texture finishes. High Build can also be used as a thicker surfacer. Mix the product with drywall compounds to achieve this effect. Pre-mixed, all-purpose and topping compounds are workable with this product. DO NOT use quick set compounds, as they will cause the film to crack and peel. To ensure consistency, box thoroughly. **Adding compounds will reduce the sheen of this product.**

Spray applied finish coat - 2 parts compound, 1 part High Build Interior Eggshell  
Hopper-sprayed spatter texture - 3 or 4 parts compound, 1 part High Build Interior Eggshell

#### SIZES: Fives

#### COLORS:

White, Swiss Coffee, Antique White. Use up to 2 ounces of Pratt & Lambert colorant per gallon for coloring to approximate commercial color matches. Use 50% of published Base 1 formulas as a starting point. Shake the product on a mechanical shaker for at least six minutes before using to completely mix the color. Check the color before using. Best results are achieved when spray-applying the material.

#### RECOMMENDED SYSTEMS:

##### NEW WORK:

##### DRYWALL

1 coat Pro-Hide Silver Interior Latex PVA Wall Primer  
1 or 2 coats of Pro-Hide Silver Interior High Build Latex Eggshell

##### PLASTER

*New*

1 coat SUPRIME Int/Ext 100% Acrylic Multi-Purpose Primer  
1 or 2 coats of PRO-HIDE Silver Interior High Build Latex Eggshell

*Old (>60 days)*

1 coat Pro-Hide Silver Interior Latex PVA Wall Primer  
1 or 2 coats of PRO-HIDE Silver Interior High Build Latex Eggshell

#### PRODUCT DETAIL:

Vehicle:	Vinyl Acrylic
Sheen:	Eggshell (5-15 @ 85°)
% Solids:	By Weight: 41% By Volume: 29%
Wt./Gallon:	10.11 lbs.
Flashpoint:	201°F. PMCC
VOC Level:	98 g/l, 0.8 lb/gl 105 g/l, 0.87 lb/gl (Antique) 98 g/l, 0.8 lb/gl (Swiss Coffee)
Thinner:	Water
Cleanup:	Soap and water
Dry Time:	@ 77°F (25°C) 50% RH: To Touch: 1.0 Hour To Recoat: 4.0 Hours
Coverage:	400 sq. ft./gallon @ 4 mils wet; .8 mils dry 50 sq. ft./ gallon @ 30 mils wet; 7 mils dry

#### APPLICATION:

Brush:	Nylon /Polyester
Roller:	3/8" nap - 3/4" nap
Sprayer:	<i>Airless</i> - 2000 psi Tip .017" - .021"

**Notes: To achieve high build properties, an airless sprayer must be used. Brush/Roller is for use as a texture finish medium only. Spray / Backroll applications will not result in high film thickness.**

Technical Information Line:  
1-800-BUY-PRAT (1-800-289-7728)  
[www.prattandlambert.com](http://www.prattandlambert.com)

## SURFACE PREPARATION:

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

### General

Remove all surface contamination by washing with appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with Pratt & Lambert SUPRIME Int/Ext 100% Acrylic Primer or SUPRIME Int/Ext Alkyd Stain Blocker.

### Drywall

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

### Masonry, Concrete, Cement, Block, Stucco, Brick

Allow new surfaces to cure according to supplier's recommendations; at least 7 days.

Remove all surface contamination (dirt, dust, grease, oil, peeling paint, heavy chalk, efflorescence, laitance, concrete dust, etc.) by washing with an appropriate cleaner; if necessary, pressure wash with a minimum of 2100 psi, rinse thoroughly and allow to dry.

Remove all form release and curing agents. On tilt-up and poured-in-place concrete, commercial detergents or sandblasting may be necessary to remove sealers, release compounds, and to provide an anchor pattern.

Repair or replace damaged or defective substrates as needed.

Allow brick to age for 1 year prior to coating.

On interior surfaces with a pH from 9 to 13, use Pro-Hide Gold Acrylic Concrete and Stucco Primer.

### Plaster

Bare plaster must be cured and hard. Treat textured, soft, porous, or powdery plaster with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.

### Caulking

Fill gaps between walls, ceilings, crown moldings, and other trim with latex or siliconized latex caulk after priming the surface.

### Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

## CLEANUP INFORMATION:

Clean spills and splatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral spirits.



## PRATT & LAMBERT PAINTS

### APPLICATION:

Apply at temperatures above 50°F.  
No reduction necessary.

#### Brush

Use a nylon/polyester brush.

#### Roller

Use a 3/8" - 3/4" nap synthetic roller cover.

#### Spray-Airless

Pressure ..... 2100 psi  
Tip ..... .017 - .021

### TIPS TO IMPROVE

#### PERFORMANCE:

- Clean the surface thoroughly.
- Prepare the substrate to create a uniform surface.
- Patch cracks, crevices, and through-wall openings using proper sealant or patch.
- Fill voids and openings around window and doors using proper sealant or patch.
- Caulk as needed using quality latex or siliconized latex caulk or sealant.

#### MAINTENANCE:

To assure maximum washability and durability, wait at least two weeks before washing the dry paint film. When removing stains, dirt, and marks, use a soft cloth or sponge with water or other general purpose household cleaner. Penetrating stains and marks can be removed either by applying a solution of household bleach in water and then rinsing with clean water; or, by carefully using an abrasive cleaner and water.

#### CAUTIONS:

For interior use only.  
Protect from freezing.  
Not for use on horizontal surfaces (floors, roofs, decks, etc.) or where water will collect.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Pratt & Lambert Paints. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Pratt & Lambert dealer or representative to obtain the most recent Product Data Sheet.